


UK +44 (0) 1438 833577 **US** +1 (603) 742 9181 www.**FUTUREAUTOMATION**.NET

fa future automation




MODEL	DESCRIPTION	MIN SCREEN HEIGHT	MAX SCREEN HEIGHT
SPS-V-5	Vertical - Single Panel	700 [27 9/16"]	800 [31 1/2"]
SPS-V-6	Vertical - Single Panel	801 [31 9/16"]	950 [37 3/8"]
SPS-V-7	Vertical - Single Panel	951 [37 7/16"]	1100[43 5/16"]
SPS-V-8	Vertical - Single Panel	1101[43 3/8""]	1250[49 3/16"]
SPS-VS-5	Vertical - Double Splitting Panel	700 [27 9/16"]	800 [31 1/2"]
SPS-VS-6	Vertical - Double Splitting Panel	801 [31 9/16"]	950 [37 3/8"]
SPS-VS-7	Vertical - Double Splitting Panel	951 [37 7/16"]	1100[43 5/16"]
SPS-VS-8	Vertical - Double Splitting Panel	1101[43 3/8""]	1250[49 3/16"]


	a a
-	VERTICAL




SPS-V

SPS-VS - VERTICAL SPLIT - DOUBLE PANEL








MODEL	DESCRIPTION	MIN SCREEN WIDTH	MAX SCREEN WIDTH
SPS-HZ-6	Horizontal - Single Panel	1400 [55 1/8"]	1600 [63"]
SPS-HZ-7	Horizontal - Single Panel	1601 [63 1/16""]	1850 [72 13/16"]
SPS-HZ-8	Horizontal - Single Panel	1851 [72 7/8"]	2100 [82 11/16"]
SPS-HZS-6	Horizontal - Double Splitting Panel	1400 [55 1/8"]	1600 [63"]
SPS-HZS-7	Horizontal - Double Splitting Panel	1601 [63 1/16""]	1850 [72 13/16"]
SPS-HZS-8	Horizontal - Double Splitting Panel	1851 [72 7/8"]	2100 [82 11/16"]

future automation

- SINGLE PANEL




SPS-HZS - HORIZONTAL SPLIT- DOUBLE PANEL




1. Panel Closed

C

SPECIFICATION MEASUREMENTS Minimum Screen Width 1400 [55 1/8"] Maximum Screen Width 1600 [63"] Minimum Screen Height 750 [29 1/2"] Maximum Screen Height 1050 [41 5/16"] Maximum Moving Panel Weight 15Kg (33lbs) 45Kg (99lb) Maximum Screen Weight Total Mechanism Weight TBC Packaging Dimensions (LxWxH) TBC Shipping Weight TBC Movement Type Motorised **Power Supply Required** 110V - 240V AC Power Consumption Max. 120W Power Consumption Standby 3W Mounting Patterns Supported VESA 400, 300, 200 W x 400, 300, 200 H **Control Options** IR Remote, RS232 Product Options / Features AB pairing option Package Contents Mechanism, IR remote control, Bolt Pack Marine Suitable Yes (Indoor)






future automation

2. Panel Retracts

TECHNICAL SHEET ISSUE 001 SHEET 3

CABINET DIMENSIONS - WIDTH AND HEIGHT



SECTION A-A



105 7/8" 2690

0 0 0

lo o oj

[13/16"]


20


105 7/8" 2690


ρίο

lo o o

future automation








TECHNICAL SHEET ISSUE 001 SHEET 4

CABINET DIMENSIONS - DEPTH

The minimum depth of 235mm [9 1/4"] allows for a maximum screen depth of 30mm [1 3/16"].

Screens with a greater thickness will need the cabinet depth to increase i.e. a 100mm [3 15/16"] thick screen will require a cabinet of 275mm [10 13/16""].


Screens thinner than 30mm [1 3/16"] must still use the minimum 235mm [9 1/4"] cabinet depth.




The moving panel retracts back by 65mm [2 9/16"] before Sliding. For this reason it is advised the front panel work and support batten is no more than 50mm [1 15/16"] thick to give 15mm [9/16"] clearance.

design.

Screen - IN




Screen - OUT




UK +44 (0) 1438 833577 **US** +1 (603) 742 9181 WWW.FUTUREAUTOMATION.NET

future automation

Thicker panels are possible, but will add to the cabinet depth and require customisation to the mechanism







UK +44 (0) 1438 833577 **US** +1 (603) 742 9181 WWW.FUTUREAUTOMATION.NET


future automation

[5 1/8"] 130


QA2 - QUAD ARM

The Quad Arm has a service mode that can be used during installation and servicing of the mechanism and the screen.


This allows the screen to be advanced out from the wall to provide access to rear of the screen and inside the mechanism during fitting.




ADVANCE - OUT




ADVANCE - SERVICE





ADVANCE - SERVICE





future automation

TECHNICAL SHEET ISSUE 001 SHEET 7

CABINET DETAILING & ACCESS

The SPS mechanism requires certain access for installation and to be serviced.

For installation the side panel must be removable to provide access to all the fixing points of the SPS mechanism.

For servicing the best option is to have the areas to the top and bottom of the opening on hinges. This will provide enough access to everything that will be needed to service and maintain the mechanism. Alternatively these panels could be made to be easily removable on suitable catches / fixings.

The Moving Panel Mechanism mounts to the top and bottom walls of the cabinet, and the Advance Bracket mounts to the back of the cabinet. It is essential that these surfaces can take the weight of the mechanism, moving panel and screen.


The mechanism is supplied with a control box on a 3m [10'] flying lead. This must be fitted in an easily accessible location. This will be the first item to be checked if there is an issue with the mechanism. Mains power and control connections (IR sensor / receiver, RS232) are all made at the control box.

Side Panel (removable for installation) To Mains Power Hinging bottom panel (removable for service & maintenance) **Contact Closure Link** Moving Panel Bracket Mechanism Cables **Power Cables**


Control box wiring loom must be routed to the bottom right corner of the cabinet.

future automation

Hinging top panel (removable for service & maintenance)







<u>NOTES</u>


- POWER SUPPLY UNIT (PSU) WILL ALLOW 110V OR 240V AC INPUT. THE SAME PSU IS USED FOR EU OR US MAINS SUPPLIES.
- OTHER THAN CONTROL CABLES, ALL CABLES TERMINATE AT CONTROL BOARD VIA STANDARD PHOENIX CONNECTORS.
- CABLE LOOM LENGTH SUPPLIED AT APPROX. 3m [118"]. LOOM CAN BE EXTENDED UP TO MAXIMUM OF APPROX. 10m [400"].
- MINIMUM CABLE BEND RADIUS 25mm [1"].

UK +44 (0) 1438 833577 **US** +1 (603) 742 9181 www.**FUTUREAUTOMATION**.NET

future automation



INSTALLATION OVERVIEW



future automation


 Mount the Mechanism side channels to the side walls of the cabinet. Ensure the mechanism mount brackets are positioned 10mm back from the edge of the front panels.




INSTALLATION OVERVIEW

Mount the moving panel to the moving panel brackets 200mm 4. from the base of the moving panel and 94mm in from the edge.

Mount the moving panel back onto the mechanism, use the slots in the 5. mount brackets to align the panel and get it into the desired position.





future automation fa

